



K9 Door PopperTM Owners Manual

by AceK9.comTM a division of Radiotronics, Inc.

Your K9 Door PopperTM is one of our state of the art products designed and developed by AceK9.comTM a division of Radiotronics, Inc. It is a unique blend of positive features taken from actual field use of our K9 LifesaverTM and Hot-N-PopTM products plus the incorporation of a new microprocessor control system. The following are a few of the new features:

Door Popper StopperTM – Extremely important Safety Feature that prevents the Door from opening when the vehicle is in motion

Unlock Feature – Unlocks the Door when it is Popped

Gas Shock – Quickly opens and holds the Door to allow the canine an unobstructed release

External Antenna – Enables very long reliable range Microprocessor Controlled Door Popper System

Software Upgradeable – As new features are developed, System can be easily updated Module design – Add new Features and Options as needs change

K9 Door PopperTM Power Up:

Turn ON K9 Door PopperTM. The Microprocessor checks the complete status of all systems. If all is OK and the vehicle is in Park or Neutral the Green LED will stay On. If the Door Popper StopperTM system senses that the Neutral Safety input is NOT OK the Green LED will blink. When the Green LED is ON solid the K9 Door PopperTM is ready for action.

K9 Door PopperTM:

The K-9 Door PopperTM will enable you to release your canine to your aid when you are away from your vehicle. The Remote Control Transmitter is very small and easy to wear or conceal. The Door Popper StopperTM Feature disables the K9 Door PopperTM when the vehicle is in motion to prevent accidental Door opening and premature exit of your canine. The Gas Shock, when installed correctly, will push and hold the Door open fully, allowing easy exit for your canine.

Insert the Remote Transmitter into the Belt Case with the button under the window area and place it on your belt in a safe and accessible location. Activate the K9 Door PopperTM by pressing the button on the Remote Control Transmitter, or by pressing the Push To Test button on the K-9 Door PopperTM Control Head when you want to release the canine.

Always make sure that the K9 Door PopperTM is disabled when the vehicle is in gear. To confirm that the Door Popper StopperTM Feature is wired and working correctly MAKE SURE that the K9 Door Popper'sTM Ready Light illuminates <u>ONLY</u> when the gear lever is in PARK OR NEUTRAL, if not, have the installer re-check the wiring. This Feature disables the Door Popper when the car is in motion. DO NOT USE THIS PRODUCT WITHOUT THIS CRITICAL SAFETY FEATURE FULLY FUNCTIONAL!

IMPORTANT: It is the responsibility of the Installer and the Handler to confirm that all safety features are installed and working properly at the time of installation. The handler is also responsible to make continuing periodic checks of all safety systems of this product.

Record Serial Numbers

Control Head Serial #______ found on Side Control head.

Remote Serial #______ found on back of remote.

Additional Other Products available from AceK9.com






Cool K9 and Cool Cop



K9 Transporters



See Acek9.com for additional information and products

